

Miniflex[®] Fiber Bag

Installation Instructions



Step 1



Unzip the cable bag and flip the top open

Step 2



Insert the fiber reel so the tabs on the bottom of the bag fit into the notches on the reel

Step 3



Pull the loose end of the fiber and thread it through the opening on the side of the bag

Step 4



Secure the fiber in the rubber cable slot and thread the fiber cable through the two cable loops

Step 5



Zip the bag closed, ensuring the tabs on the bag flap fit into the spool to complete the install