

3-Piece Pin Connector for QR Cable



Connector Diagram




Fig. 1

Cable Preparation

1. Cut ends of cable square.




Fig. 2

2. Core cable and strip back Aluminum sheath and Jacket to expose the center conductor using a commercially available core/strip tool as shown in Figure 2.
3. Remove dielectric residue from center conductor exposed beyond cable outer conductor. Use care not to scratch surface by using an approved non-metallic center conductor cleaning tool or a Plexiglas scraper with squared or serrated edge works well, Figure 3.




Fig. 3

4. **Verify cable center conductor length** by using the CUT MARK on the connectors MAIN NUT as shown in Figure 4. Using diagonal cutters, make a cut half way through center conductor then rotate cutters 90° and complete the cut to give a pencil type point as shown in Figure 5.




Fig. 4




Fig. 5

5. Strip back the jacket to expose the Aluminum Sheath by using Jacket Strip tool supplied with the tool kit as shown in Figure 2.

3-Piece Pin Connector for QR Cable



Connector Attachment

1. Loosen seizure screw inside equipment. Cut pin on connector **MAIN BODY**, if necessary, to the equipment manufacturer's specification. Fully hand-tighten the **MAIN BODY** into equipment port then an additional 1/8 to 1/4 turn using wrench (20 - 25 ft/lbs.).
2. If using heat shrink, slide tubing over cable at this time.
3. Install connector **BACK NUT** onto cable.
4. Fully insert the **MAIN NUT** onto the prepared cable.
5. Bring the connector **MAIN NUT** and cable to the connector **MAIN BODY** as shown in Figure 6. Fully hand-tighten **MAIN NUT** to **MAIN BODY** while keeping force on the cable towards the **MAIN BODY**.




Fig. 6

6. Using two wrenches, one wrench to hold the **MAIN BODY** from rotation, continue tightening the **MAIN NUT** to the **MAIN BODY** until the positive stop is engaged as shown in Figure 7. The front leading edge of **MAIN NUT** will contact the mating surface of the **MAIN BODY** causing an increase in the tightening torque.




Fig. 7

7. Tighten **BACK NUT** by hand, then, using two wrenches, one on the **MAIN NUT**, complete the installation by tightening **BACK NUT** until the positive stop is engaged as shown in Figure 8. The front leading edge of **BACK NUT** will contact mating surface of the **MAIN NUT** causing an increase in the tightening torque.




Fig. 8

8. Tighten seizure screw inside equipment port to manufacturer's specification.
9. Slide the heat shrink tubing over the connector against the equipment port and shrink in accordance with manufacturer's recommendation.

These products may be protected by one or more patents • For further information, please visit: www.ppc-online.com/patents