

# EXT/EXT3/EXT4.5/EXT6 Install Instructions



## PRODUCT IMAGE:



1. Measure and trim the pin of the mating connector that will be installed into the extender to 9/16", measured from front surface of the connector. To ease installation, cut the pins at an angle.
2. Use a twisting motion to insert the cut pin into the socket of the Female Splice Coupler. Hand tighten, then tighten an additional 1/8 to 1/4 turn with a wrench.

