NX90 Install Instructions



PRODUCT IMAGE:



- 1. Loosen the equipment seizure screws.
- 2. Measure and trim the pin of the Right Angle Adapter according to equipment manufacturer's specification.
- 3. Thread the Right Angle Adapter into the equipment housing approximately 4 turns.
- 4. Trim the pin of the connector to 3/4". Use the width of the Right Angle Adapter as a pin trim guide.
- 5. Hand tighten the pin connector into the Right Angle Adapter. Wrench tighten an additional 1/8 to 1/4 turn while holding the adapter stationary with another wrench.
- 6. Install the prepared cable into the pin connector and fully tighten per the connector installation instructions.
- 7. Hand tighten the jam nut of the Right Angle Adapter to the equipment housing while holding the adapter stationary, then further tighten the port nut 1/8 to 1/4 turn with a wrench.
- 8. Tighten the seizure screw within the equipment housing according to the manufacturer's specification.

